



- 1) SLIDE PACKAGE RECEIVER IN OPENING FROM EXTERIOR SIDE OF WALL OR BUILDING.
- 2) SLIDE ALL THE WAY IN UNTIL FLANGE IS FLUSH WITH THE EXTERIOR SIDE OF BUILDING.
- 3) SLIDE THREE SIDED FLANGE OVER THE BACK OF PACKAGE RECEIVER UNTIL FLUSH WITH INTERIOR WALL.
- 4) MARK FOR HOLES, DRILL, TAP AND SCREW APPLY REAR FLANGE SECURING THE PACKAGE RECEIVER IN PLACE

NOTE: 5/32 DRILL BIT AND 10-32 TAP SUPPLIED BY OTHERS. SCREWS SHOULD BE 3/8" LONG.

NOTE: THIS DRAWING EMBODIES A CONFIDENTIAL PROPRIETY DESIGN ORIGINATED AND OWNED BY QUIKSERV CORP., AND IS SUBMITTED UNDER A CONFIDENTIAL RELATIONSHIP. ALL PATENT, MANUFACTURING, SALE RIGHTS REGARDING THE SAME ARE RESERVED EXCEPT TO THE EXTENT RIGHTS ARE EXPRESSLY GRANTED TO OTHERS. THE RECIPIENT AGREES BY ACCEPTING THESE DRAWINGS NOT TO SUPPLY OR DISCLOSE ANY INFORMATION REGARDING THEM TO ANY UNAUTHORIZED PERSON.

Rough Opening:
15-1/2" (W) X 15-1/2" (H)

Represented by:
Interbank-Exchange, LLC
P.O. Box 632
Black Canyon City, AZ

PR-1515 INSTALLATION DRAWING			Actual Dimension: 15-3/16" (W) X 15-3/16" (H)
Drawing Name: PR-1515 INSTALLATION		Transfer Area: 13-1/2"(W) X 13-3/4"(H) X 15-3/8"(D)	
Date: 12/23/2009	Drawn By: BC	Scale: 1:5	